

=====

IM-700 Driver Set for Windows XP

=====

1) Chipset Software Installation Utility

This utility enables the use of the following functions of the Chipset.

- Core PCI and ISAPNP Services**
- USB Support**
- Identification of Intel(R) Chipset Components in Device Manager**

2) POS Device Driver

This driver enables the use of the POS Device functions.

3) SATA-RAID Driver

This driver enables the use of the Serial ATA Hard Drive and the RAID functions.

4) Touch Panel Driver

This driver enables operation of Windows programs by touching the Touch Panel on the Windows instead of the mouse operation.

5) Video Driver

This driver enables the use of the Video functions.

2. Contents

1) This folder is constructed as follows.

- + CHIPSET - Chipset Software Installation Utility**
- + POSDVCFG - POS Device Driver**
- + SATARAID - SATA-RAID Driver**
- + TOUCH - Touch Panel Driver**
- + VIDEO - Video Driver**

"Chipset Software Installation Utility" must be used before installing other drivers.

3. Installation method

1) Chipset Software Installation Utility

Executing the INFINST_ENU.EXE in the CHIPSET folder, please follow the instructions of the setup wizard.

2) POS Device Driver

- Windows XP -

Follow these instructions

- 1. Click "Start", and click "Control Panel".**
- 2. Click "Performance and Maintenance".**
- 3. Click the "System" icon and open "System Properties".**
- 4. Click the tab of "Device Manager".**
- 5. Click "POS Device Controller" of "Other Devices".**
- 6. Click "Properties".**
- 7. Click "Reinstall Driver".**

Windows start the Hardware Update Wizard.

- 8. You will be prompted to select a search method.**

Choose No, not this time. Click Next.

- 9. You will be prompted to select an installation method.**

Choose Install from a list or specific location (Advanced).

Click Next.

- 10. On the choose your search and installation option screen, choose to Include this location in the search.**

Click Browse and select the POSDVCFG\DRIVER folder.

- 11. As the installation begins, you will receive a message regarding Microsoft logo testing and driver compatibility with Windows XP.**

Click Continue Anyway.

- 12. The Hardware Update Wizard will now tell you it has finished installing drivers.**

Click Finish.

3) SATA-RAID Driver

Preparing a 'Silicon Image SiI 3x12 Raid Driver Installation Disk'

Follow these instructions if you are creating a diskette containing the Silicon Image SiI 3x12 Raid driver.

- 1. Format a blank floppy diskette.**
- 2. Copy all the files contained in SATARAID\DRIVER folder to the newly formatted diskette.**
- 3. Label this floppy diskette 'Silicon Image SiI 3x12 RAID Driver Installation Disk'.**

Follow these instructions

- 1. Put your Windows XP CD into the CD-ROM/DVD drive and boot from the CD.**
- 2. Press F6 for third party SCSI or driver installation at the beginning of text mode installation. Press 's' when setup asks if you want to specify an additional device, and insert the diskette labeled 'Silicon Image SiI 3112 SATARaid Driver Installation Disk' .**

Press 'Enter' and select

'Silicon Image SiI 3112 SATARaid Controller'

- 3. Press 'Enter' to continue on with text mode setup.**
- 4. Follow the setup instructions to select your choice for partition and file system.**

4) Touch Panel Driver

After executing the EPSTPWDM.EXE in the TOUCH folder, please follow the instructions from the setup wizard.

5) Video Driver

After executing the WIN2K_XP1413.EXE in the VIDEO folder, please follow the instructions from the setup wizard.

For more details, please see the README.TXT in the VIDEO holder.