

CD-7220-UN
5V USB SERIES
VACUUM FLUORESCENT
CUSTOMER DISPLAY
MANUAL

CD-7220-UN 5V USB SERIES CUSTOMER DISPLAY

INDEX

1. INTRODUCTION	3
2. FEATURES	4
3. GENERAL SPECIFICATIONS	5
4. INTERFACE SPECIFICATIONS.....	5
5. SYSTEM COMMAND DETAILS.....	6
6. COMMAND.....	8
7. INSTALLATION GUIDE	17

CD-7220-UN 5V USB SERIES CUSTOMER DISPLAY

1. INTRODUCTION

Thank you for choosing the CD-7220-UN 5V USB VFD Customer Pole Display. The CD-7220-UN 5V USB provides both reliability and performance in a professional looking design. In this guide, you will find connection and configuration information to help you connect the display to your computer. If you are a programmer, you will find interface command details to allow you to exploit the advanced features of the display.

The CD-7220-UN 5V USB customer pole display uses a vacuum fluorescent display (VFD) tube presenting bright and easy to read characters. Because of the VFD technology the display is viewable from a wide angle. Users will appreciate not having to remain in a fixed viewing position to see the display, they will be free to move forward in line and still keep the display readable. The CD-7220-UN 5V USB customer pole display has 2 pole sections giving you the choice of 4 different display heights. The display can be rotated up to 270°. The head of the display can tilt by up to 35°. The combination of these features gives you flexibility to tailor the display position to your unique application.

With 2 lines of 20 characters on CD-7220-UN 5V can display alphanumeric messages with 13 international characters. Additionally, software utility is provided to transfer character dot pattern to ASCII code giving you the ability to defined characters and demo message to download to the display MCU.

CD-7220-UN 5V USB offers a variety of emulation modes including CD-5220II, Epson, ADM787, ADM788, Aedes, Emax and Ultimate. CD-7220's universal design gives you the flexibility to choose the application software best suited for your POS requirement.

CD-7220-UN 5V USB SERIES CUSTOMER DISPLAY

2. FEATURES

- 20 columns x 2 lines for each side .
- Getting power direct from 5V USB, no external power adapter.
- Display panel is adjustable both by tilting vertically and rotating horizontally.
- Configuration of command emulation mode, and user-defined font is selectable by window based support software or by using external setting box.
- XP & Vista WHQL certified driver.
- Command emulation modes include CD5220II, Epson, ADM787, ADM788, Aedex, Emax and Ultimate.
- Support software has facility for designing user-defined characters and downloading setup parameters to the display. Once in the display new characters are stored in MCU.
- Display windowing commands are available using CD5220 or Epson command sets.

CD-7220-UN 5V USB SERIES CUSTOMER DISPLAY

3. GENERAL SPECIFICATIONS

ITEM	CD-7220-UN	CD-7220-UN-D
Display Method	Vacuum fluorescent display	
Number of Characters	40 characters (20 columns × 2 lines)	80 characters (20 columns × 2 lines on each side)
Display Color	Blue Green	
Brightness	700 cd/m2	
Character Type	96 alphanumeric - 13 international character sets including US, French, Germany, Spanish, etc. - One set downloadable set-up parameter, and character font	
Character Font	5 x 7 dot matrix, comma and decimal point	
Character Size	9.0mm × 5.25mm	
Interface	USB (version 2.0)	
Driver	Windows XP & Vista driver (WHQL/WLK certified) OPOS driver	
Power Supply	Without external adapter, use 5V USB	
Power Consumption	5W	8W
MTBF	25,000 hours	
View Angle	8—35 degrees	
Rotation angle	maximum 270 degrees	
Dimensions (Head)	230 (W) × 80 (H) × 40 (D) mm	
Operating Temperature	0~40 degree C	
Storage Temperature	-20~60 degree C	
Operating Humidity	15~80%	
Storage Humidity	15~80%	

Note: For CD-7220-UN-D model, please make sure both USB connectors are plugged.

Table 1-1

4. INTERFACE SPECIFICATIONS

PC/HOST communicates with display CD7220-UN 5V only through USB cable. Before you use the display CD7220-UN 5V, you must install the direct USB driver for it!

CD-7220-UN 5V USB SERIES CUSTOMER DISPLAY

5. SYSTEM COMMAND DETAILS

5.1 International character set

STX 05 S n ETX Change international character set
 ASCII Format STX 05 S n ETX
 Dec. Format [02][05][83] n [03]
 Hex. Format [02h][05h] [53h] n [03h] 30h ≤ n ≤ 3fh
 Description Change the display international character font. A total of 16 different character fonts to select from. The setting function will be saved to EEPROM.

n	International font	n	International font
30h	U.S.A	38h	JAPAN
31h	FRANCE	39h	NORWAY
32h	GERMANY	3Ah	DENMARK II
33h	U.K	3Bh	SLAVONIC
34h	DENMARK I	3Ch	RUSSIA
35h	SWEDEN	3Dh	Factory define
36h	ITALY	3Eh	Factory define
37h	SPAIN	3Fh	User define pattern

5.2 Command type select

STX 05 C n ETX Change command type
 ASCII Format STX 05 C n ETX
 Dec. Format [02][05][67] n [03]
 Hex. Format [02h][05h] [43h] n [03h] 30h ≤ n ≤ 37h
 Description This command will change the command type and initialize the display. The display emulation mode is based on CD5220II/ESC POS/ADM787/ADM788/ UTC/AEDEX/EMAX mode. The setting function will be saved to EEPROM.

n	Command type	n	Command type
30h	DSP800	34h	AEDEX
31h	ESC/POS	35h	UTC/P
32h	ADM788	36h	UTC/S
33h	ADM787	37h	CD5220

5.3 Reset EEPROM

STX 05 07 n ETX Reset EEPROM
 ASCII Format STX 05 07 n ETX
 Dec. Format [02][05][07][n][03]
 Hex. Format [02h][05h][07h][n][03h]
 Description This command will reset the content of EEPROM (eg. demo scroll data, user-define character, baud rate setting.)
 n=31h clear all EEPROM contents
 n=32h clear upper line data message
 n=33h clear lower line data message

5.4 Save data for demo display

STX 05 L n m ETX Save demo message to EEPROM
 ASCII Format STX 05 L n m ETX
 Dec. Format [02][05][76] n m [03]
 Hex. Format [02h][05h][4Ch] n m [03h]
 Description Save demo message for upper line and bottom line
 n = 31h save data message for upper line
 n = 32h save data message for lower line
 m = data message; the maximum data character is under 200

CD-7220-UN 5V USB SERIES CUSTOMER DISPLAY

5.5 Run Demo message

STX 05 D 08 ETX Run demo message
ASCII Format STX 05 D 08 ETX
Dec. Format [02][05][68][08][03]
Hex. Format [02h][05h][44h][08][03h]
Description Run demo message for the display

5.6 Set Communication Option

STX 05 P n ETX Set the communication parity
ASCII Format STX 05 P n ETX
Dec. Format [02][05][80] n [03]
Hex. Format [02h][05h][50h] n [03h] $31h \leq n \leq 36h$
Description Change the display communication parity. Set 7 or 8 data bit and the parity set for even, odd, or non-parity.

n	Parity
31h	N-8-1
32h	N-7-1
33h	E-8-1
34h	E-7-1
35h	O-8-1
36h	O-7-1

CD-7220-UN 5V USB SERIES CUSTOMER DISPLAY

6. COMMAND

6.1 Command list

6.1.1 CD 5220-II STANDARD MODE

Command	Code description (hex)	Function description
ESC DC1	1B 11	overwrite mode
ESC DC2	1B 12	vertical scroll mode
ESC DC3	1B 13	horizontal scroll mode
ESC Q ACR	1B 51 41 [n]x20 0D	set the string display mode, write string to upper line
ESC Q BCR	1B 51 42 [n]x20 0D	set the string display mode, write string to lower line
ESC Q DCR	1B 51 44 [n]x20 0D	upper line message scroll continuously
ESC [D	1B 5B 44	move cursor left
BS	08	move cursor left
ESC [C	1B 5B 43	move cursor right
HT	09	move cursor right
ESC [A	1B 5B 41	move cursor up
ESC [B	1B 5B 42	move cursor down
LF	0A	move cursor down
ESC [H	1B 5B 48	move cursor to home position
HOM	0B	move cursor to home position
ESC [L	1B 5B 4C	move cursor to left-most position
CR	0D	move cursor to left-most position
ESC [R	1B 5B 52	move cursor to right-most position
ESC [K	1B 5B 4B	move cursor to bottom position
ESC l x y	1B 6C x y 1≤x≤20,y=1,2	move cursor to specified position
ESC @	1B 40	initialize display
ESC W s x1 x2 y	1B 57 1 x1 x2 y 1≤x1≤x2≤20 y=1,2	reset window range at horizontal scroll mode
CLR	0C	clear display screen, and clear string mode
CAN	18	clear cursor line, and clear string mode
ESC * n	1B 2A n 1≤n≤4	brightness adjustment
ESC & s n m [a(p1..pa)]x (m-n+!)	1B 26 1 n m [a(p1..pa)]x (m-n+1) 20h<n≤m≤FFh a=1-5 , p1..p5 =row1..row5	define download characters.
ESC ?	1B 3F	delete download characters.
ESC %	1B 25	select/cancel download character set.
ESC _ n	1B 5F n n=0,1	set cursor ON/OFF
ESC f n	1B 66 n	select international fonts
ESC c n	1B 63 n	select fonts, ASCII code or JIS code
ESC s 1	1B 73 01	store user-define character into EEPROM
ESC d 1	1B 64 01	restore user-define character from EEPROM
ESC = n	1B 3D n n=1; enable printer, disable display (Do not use) n=2; disable printer, enable display n=3; enable printer, enable display n=4; message for customer side (for CD7220-UN-D only) n=5; message for operator side (for CD7220-UN-D only) default n=2	select peripheral device, display or printer: display for customer side or display for operator side

Table 6-1

(REMARK)

- * While using command "ESC QA" or "ESC QB", these two commands can be used with terminal printer: TP2688 or TP3688
- * While using command "ESC QA" or "ESC QB", other commands can not be used except when using command "CLR" or "CAN" to change operating mode.
- * When using command "ESC QD", the upper line message will scroll continuously until a new command is received, it will then clear the upper line and move the cursor to the upper left-end position.

CD-7220-UN 5V USB SERIES CUSTOMER DISPLAY

Set international font for CD7220 (Table 6-2)

n	International font set	n	International font set
A	U.S.A.	N	NORWAY
G	GERMANY	W	SWEDEN
I	ITALY	D	DENMARK I
J	JAPAN	E	DENMARK II
U	U.K.	L	SLAVONIC
F	FRANCE	R	RUSSIA
S	SPAIN		reserved

Select code for CD7220 (Table 6-3)

n	International code set
A	Compliance with ASCII code
J	Compliance with JIS code
R	Compliance with RUSSIA code
L	Compliance with SLAVONIC code
P	PC858
W	WPC1252

6.1.2 ADM787/788 command list

Command	Code description (hex)	Function description
CLR	0C	clear display
CR	0D	carriage return
SLE1	0E	clear upper line and move cursor to upper left-end position
SLE2	0F	clear bottom line and move cursor to bottom left-end position
DC0	10 n	set period to upper line, last n position $31h \leq n \leq 37h$
DC1	11 n	set line blinking, upper line n='1', bottom line n='2'
DC2	12 n	clear line blinking, upper line n='1', bottom line n='2'
SF1	1E	clear field 1 and move cursor to field 1, first position
SF2	1F	clear field 2 and move cursor to field 2, first position

Table 6-4

6.1.3 UTC standard mode command list

Command	Code description (hex)	Function description
BS	08	back space
HT	09	horizontal tab
LF	0A	line feed
CR	0D	carriage return
DLE	0F	display position
DC1	11	overwrite display mode
DC2	12	vertical scroll mode
DC3	13	cursor on
DC4	14	cursor off
ESC d	1B 64	change to UTC enhanced mode
US	1F	clear display

Table 6-5

6.1.4 UTC enhanced mode command list

Command	Code description (hex)	Function description
ESC u ACR	1B 75 41 [data x 40] 0D	upper line display
ESC u BCR	1B 75 42 [data x 40] 0D	bottom line display
ESC u DCR	1B 75 44 [data x 40] 0D	upper line message scroll continuously
ESC u ECR	1B 75 45 hh ':' mm 0D h,m='0'-'9'	display time
ESC u FCR	1B 75 46 [data x 40] 0D	upper line message scroll once
ESC u HCR	1B 75 48 n m 0D $20h \leq n, m$	change attention code
ESC u ICR	1B 75 49 [data x 40] 0D	two line display
ESC RS CR	1B 0F 0D	change to UTC standard mode

Table 6-6

CD-7220-UN 5V USB SERIES CUSTOMER DISPLAY

6.1.5 AEDEX mode command list

Command	Code description (hex)	Function description
! # 1CR	21 23 31 [data x 40]	upper line display
! # 2CR	21 23 32 [data x 40]	bottom line display
! # 4CR	21 23 34 [data x 40]	upper line message scroll continuously
! # 5CR	21 23 35 hh ':' mm 0D h,m='0'-'9'	display time
! # 6CR	21 23 36 [data x 40]	upper line message scroll once pass
! # 8CR	21 23 38 n m 0D 20h≤n,m	change attention code
! # 9CR	21 23 39 [data x 40]	two line display

Table 6-7

6.1.6 DSP-800 mode command list

Command	Code description (hex)	Function descriptions
EOT SOH I n ETB	04 01 49 n 17	select international character set
EOT SOH P n ETB	04 01 50 n 17 n=31h-58h	move cursor to specified position
EOT SOH C n m ETB	04 01 43 n m 17 31h≤n≤m≤58h	clear display range from <u>n</u> position to <u>m</u> position and move cursor to <u>n</u> position
EOT SOH S n ETB	04 01 53 n 17 n=31h-35h	save current view message to n layer for demo view data
EOT SOH D n m ETB	04 01 44 n m 17 n=31h-4Fh m=31h-33h	display the saved demo message
EOT SOH A n ETB	04 01 41 n 17 n=31h-34h	brightness adjustment
EOT SOH F n ETB	04 01 46 n 17 00h≤n≤FFh	blink display screen
EOT SOH & n [px5] ETB	04 01 26 n p1...p5 17, 20h≤n	define download characters
EOT SOH ? n ETB	04 01 3F n 17 20h≤n	delete download characters
EOT SOH = n ETB	04 01 3D n 17	select peripheral device select printer n='1', display n='2'
EOT SOH % ETB	04 01 25 17	initialize display
EOT SOH @ ETB	04 01 40 17	execute self-test
EOT SOH B n N ETB	04 01 42 n 4E 17 n=31h-36h	set baud rate and parity

Table 6-8

(REMARK)

* International font set (Table 6-9)

n	International font set
30h	U.S.A.
31h	France
32h	Germany
33h	U.K.
34h	Denmark I
35h	Sweden
36h	Italy
37h	Spain
38h	Japan
39h	Norway
3Ah	Denmark II

CD-7220-UN 5V USB SERIES CUSTOMER DISPLAY

6.1.7 EPSON ESC/POS command list

Command	Code description(hex)	Function description
HT	09	move cursor right
BS	08	move cursor left
US LF	1F 0A	move cursor up
LF	0A	move cursor down
US CR	1F 0D	move cursor to right-end position
CR	0D	move cursor to left-end position
HOM	0B	move cursor to home position
US B	1F 42	move cursor to bottom position
US \$ x y	1F 24 x y $1 \leq x \leq 20, y=1,2$	move cursor to specified position
CLR	0C	clear display screen
CAN	18	clear cursor line
US X n	1F 58 n $1 \leq n \leq 4$	brightness adjustment
US E n	1F 45 n $0 \leq n \leq 255$	blink display screen
ESC @	1B 40	initialize display
ESC t n	1B 74 n $1 \leq n \leq 0x0F$	select character code table
ESC R n	1B 52 n $1 \leq n \leq 0x0F$	select international character set
US r n	1F 72 n $n=0,1$	select/cancel reverse character
US MD1	1F 01	specify overwrite mode
US MD2	1F 02	specify vertical scroll mode
US MD3	1F 03	specify horizontal scroll mode
ESC & s n m [a(p1..pa)]x m-n	1B 26 1 n m [a(p1..pa)]x m-n 20h<n<m<FFh; a=1-5, p1..p5=row1..row5	define download characters
ESC ?	1B 3F	delete download characters
ESC %	1B 25	select/cancel download character set
ESC W n s x1 y1 x2 y2	1B 57 n s x1 y1 x2 y2 n=1-4, s=0,1, $1 \leq x1 \leq x2 \leq 20$; $1 \leq y1 \leq y2 \leq 2$	reset window range
ESC = n	1B 3D n (default n=2) n=1; enable printer, disable display (Do not use) n=2; disable printer, enable display n=3; enable printer, enable display n=4; message for customer side (For CD7220-UN-D only) n=5; message for operator side (For CD7220-UN-D only)	select peripheral device
US :	1F 3A	set starting/ending position to define macro
US ^ n m	1F 5E n m, $0 \leq (n, m) \leq 255$	execute and quit macro
US @	1F 40	execute self-test
ESC s 1	1F 73 01	store defined download character to EEPROM
ESC d 1	1F 64 01	restore user-define character from EEPROM
ESC T h m	1B 54 h m, $0 \leq h \leq 23$ $0 \leq m \leq 59$	display time
US . n	1F 2E n, n = a displayable character code	specify period
US , n	1F 2C n, n = a displayable character code	specify comma
US ; n	1F 3B n, n = a displayable character code	specify semicolon (period + comma)
US # n m	1F 23 n m, n = 0 or 1, $0 \leq m \leq 20$	turn annunciator ON/OFF

Table 6-10

CD-7220-UN 5V USB SERIES CUSTOMER DISPLAY

Set international font for ESC/POS (Table 6-11)

n	International font set	n	International font set
0	U.S.A.	7	SPAIN
1	FRANCE	8	JAPAN
2	GERMANY	9	NORWAY
3	U.K.	10	DENMARK II
4	DENMARK I	11	SLAVONIC
5	SWEDEN	12	RUSSIA
6	ITALY	15	Reserved

Select code for ESC/POS (Table 6-12)

n	International font set (80H-FFH)
0	Page 0,(PC437:U.S.A.,standard Europe)
1	Page 1,(Katakana for Japan)
2	Page 2,(PC850:multilingual)
3	Page 3,(PC860:Portuguese)
4	Page 4,(PC863:Canadian-French)
5	Page 5,(PC865:Nordic)
6	Page 6,(SLAVONIC)
7	Page 7,(RUSSIA)
13	Page 8,(PC858:Euro)
10	Page 9,(WPC1252)

6.2 CD7220 standard command details

ESC DC1 /Overwrite mode/

ASCII Format ESC DC1

Dec. Format [027][017]

Hex. Format [1Bh][11h]

Description Change the display mode to the overwrite mode. In this mode, the cursor will move rightward and begin from the upper left-end position. When the cursor reached the end of the upper line, the cursor will move down to the bottom left-end position to continue. When the cursor reached the end of the bottom line, it will move up to the upper left-end position and overwrite the previous characters.

ESC DC2 /Vertical scroll mode/

ASCII Format ESC DC2

Dec. Format [027][018]

Hex. Format [1Bh][12h]

Description Change the display mode to the vertical scroll mode. In this mode, the cursor will move rightward. The cursor will begin from the upper left-end position until it reached the end of the upper line, the cursor will then move down to the bottom left-end position to continue until it reached the end of the bottom line. Then, CD7220 will scroll the bottom line up to replace the upper line. The bottom line will be cleared, and the cursor will continue to the first position of the bottom line.

ESC DC3 /Horizontal scroll mode/

ASCII Format ESC DC3

Dec. Format [027][019]

Hex. Format [1Bh][13h]

Description Change the display mode to the horizontal mode. In this mode, the extend of the cursor activity is bond by predefined range, limited to the upper line. (Please refer to Set or cancel window command), where the default window is the whole upper line. Once the cursor activity reached the end of the range, the characters that comes there after will push displayed characters forward from behind.

ESC Q A d1d2d3d4d5d6.....dn CR

ESC Q B d1d2d3d4d5d6.....dn CR /Set the string display mode, and write string to display/

ASCII Format ESC Q A d1d2d3d4d5d6...dn CR

ESC Q B d1d2d3d4d5d6...dn CR

Dec. Format [027][081][065] d1d2d3..dn [013]

[027][081][066] d1d2d3..dn [013]

Hex. Format [1Bh][51h][41h] d1d2d3..dn [0Dh]

[1Bh][51H][42h] d1d2d3..dn [0Dh] {20h≤dn≤ffh}

Description Set the string display mode, write to upper or lower line d1 d2 d3 . . . dn {1≤n≤20}

“A” stands for the upper line, “B” stands for the lower line. The string display mode will be cancelled and back to last mode after receive CLR or CAN.

ESC Q D d1d2d3d4d5d6.....dn CR /Upper line message scroll continuously

ASCII Format ESC Q D d1d2d3d4d5d6...dn CR

Dec. Format [027][081][068] d1d2d3..dn [013]

Hex. Format [1Bh][51h][44h] d1d2d3..dn [0Dh] {20h≤dn≤ffh}

Description The message (previously defined) will scroll continuously in the horizontal direction until a new

CD-7220-UN 5V USB SERIES CUSTOMER DISPLAY

	command is received.
ESC [D	/Move cursor left/
BS	/Move cursor left/
ASCII Format	ESC [D
Dec. Format	[027][091][068]
Hex. Format	[1Bh][5Bh][44h]
ASCII Format	BS
Dec. Format	[008]
Hex. Format	[08h]
Description	When the current cursor is at the left-end position, this command operates differently depends on the display mode. <ol style="list-style-type: none"> 1. Overwrite mode: When the cursor reached the left-end of the lower line, it will continue to the right-end of the upper line, overwrite previous characters. When it reached the left end of the upper line, it will continue to the right-end of the lower line. 2. Vertical scroll mode: When the cursor reached the left-end of the lower line, the lower line will scroll up and replace the previous upper line, the lower line will be cleared and the cursor will continue to the right end of the lower line. 3. Horizontal scroll mode: The cursor will remain stationary.
ESC [C	/Move cursor right/
HT	/Move cursor right/
ASCII Format	ESC [C
Dec. Format	[027][091][067]
Hex. Format	[1Bh][5Bh][43h]
ASCII Format	HT
Dec. Format	[009]
Hex. Format	[09h]
Description	Move the cursor to the right. When the cursor reached the right-end, this command operates differently depending on the display mode. <ol style="list-style-type: none"> 1. Overwrite mode: When the cursor reached the right-end of the lower line, it will continue to the left-end of the upper line, overwrite previous characters. When it reached the right-end of the upper line, it will continue to the right-end of the lower line. 2. Vertical scroll mode: When the cursor reached the right-end of the lower line, the lower line will scroll up to replace the upper line, the lower line is cleared and ready to continue characters there after. 3. Horizontal scroll mode: The cursor will remain stationary.
ESC [A	/Move cursor up/
ASCII Format	ESC [A
Dec. Format	[027][091][065]
Hex. Format	[1Bh][5Bh][41h]
Description	Move the cursor up one line. When the cursor is on the upper line, this command operates differently depending on the display mode. <ol style="list-style-type: none"> 1. Overwrite mode: The cursor is moved to the same column on the lower line. 2. Vertical scroll mode: The characters display on the upper line are scrolled to the lower line, and the upper line is cleared. The cursor will remain at the same position. 3. Horizontal scroll mode: The cursor will remain stationary.
ESC [B	/Move cursor down/
LF	/Move cursor down/
ASCII Format	ESC [B
Dec. Format	[027][091][066]
Hex. Format	[1Bh][5Bh][42h]
ASCII Format	LF
Dec. Format	[010]
Hex. Format	[0Ah]
Description	Move the cursor down one line. When the cursor reached the lower line, this command operates differently depending on the display mode. <ol style="list-style-type: none"> 1. Overwrite mode: The cursor is moved to the same column on the upper line. 2. Vertical scroll mode: The characters display on the lower line are scrolled to the upper line, and the lower line is cleared. The cursor will remain at the same position. 3. Horizontal scroll mode: The cursor will remain stationary.

CD-7220-UN 5V USB SERIES CUSTOMER DISPLAY

ESC [H	/Move cursor to home position/
HOM	/Move cursor to home position/
ASCII Format	ESC [H
Dec. Format	[027][091][072]
Hex. Format	[1Bh][5Bh][48h]
ASCII Format	HOM
Dec. Format	[011]
Hex. Format	[0Bh]
Description	The cursor will move to the left-end position of the upper line
ESC [L	/Move cursor to left-most position/
CR	/Move cursor to left-most position/
ASCII Format	ESC [L
Dec. Format	[027][091][076]
Hex. Format	[1Bh][5Bh][4Ch]
ASCII Format	CR
Dec. Format	[013]
Hex. Format	[0Dh]
Description	The cursor will be moved to the left-end position of the current line.
ESC [R	/Move cursor to right-most position/
ASCII Format	ESC [R
Dec. Format	[027][091][082]
Hex. Format	[1Bh][5Bh][52h]
Description	The cursor will be moved to the right-end position of the current line.
ESC [K	/Move cursor to bottom position/
ASCII Format	ESC [K
Dec. Format	[027][091][075]
Hex. Format	[1Bh][5Bh][4Bh]
Description	The cursor will be moved to the right-end position on the lower line.
ESC 1 x y	/Move cursor to specified position/
ASCII Format	ESC 1 x y
Dec. Format	[027][108] x y { 1≤x≤20 , 1≤y≤2 }
Hex. Format	[1Bh][6Ch][x][y]
Description	The cursor will be moved to the x column on the y line.
ESC @	/Initialize display/
ASCII Format	ESC @
Dec. Format	[027][064]
Hex. Format	[1Bh][40h]
Description	The data in the input buffer will be cleared and reset from default.
ESC W s x1x2 y	/Reset the window/
ASCII Format	ESC W s x1 x2 y
Dec. Format	[027][087][000]
Hex. Format	[027][087][001] x1 x2 y { 1≤x1≤x2≤20 , 1≤y≤2 }
Description	Reset the window on the display. When s = 0, window is cancelled (values: x1, x2, and y are not required.) When s = 1 the window will be reset (values: x1, x2, and y are required.) The x1 and x2 set the position of the left column and right column, respectively, of the window. The y sets the upper line or the lower line of the window. This function is valid within the horizontal mode.

CD-7220-UN 5V USB SERIES CUSTOMER DISPLAY

CLR /Clear display screen, and clear string mode/
 ASCII Format CLR
 Dec. Format [012]
 Hex. Format [0Ch]
 Description All the display characters will be cleared, and the string mode will be cancelled.

CAN /Clear current line, and cancel string mode/
 ASCII Format CAN
 Dec. Format [024]
 Hex. Format [18h]
 Description The current line is cleared, and the string mode is cancelled.

ESC * n /Brightness adjustment /
 ASCII Format ESC * n
 Dec. Format [027][042] n {3<=n<=4}
 Hex. Format [1Bh][2Ah][n]
 Description Adjust the brightness of the vacuum fluorescent display.
 When n = 3 ,brightness = 70 %
 When n = 4 ,brightness =100 %

ESC _ n /Set cursor ON or OFF /
 ASCII Format ESC _ n
 Dec. Format [027][095] n {0<=n<=1}
 Hex. Format [1Bh][5Fh][n]
 Description: Set cursor ON or OFF
 When n = 0, cursor is OFF
 When n = 1, cursor is ON

ESC f n /Select international font/
 ASCII Format ESC f n
 Dec. Format [027][102] n
 Hex. Format [1Bh][66h][n]
 Description Set international font

n	International font set	n	International font set
A	U.S.A.	N	NORWAY
G	GERMANY	W	SWEDEN
I	ITALY	D	DENMARK I
J	JAPAN	E	DENMARK II
U	U.K.	L	SLAVONIC
F	FRANCE	R	RUSSIA
S	SPAIN		reserved

Table 6-11

ESC c n /Select fonts /
 ASCII Format ESC c n
 Dec. Format [027][099] n
 Hex. Format [1Bh][63h][n]
 Description Select fonts

n	International font set	n	International
A	compliance with ASCII code	R	compliance with RUSSIA code
J	compliance with JIS code	L	compliance with SLAVONIC code

Table 6-12

CD-7220-UN 5V USB SERIES CUSTOMER DISPLAY

ESC = n	/Select peripheral device, Display or Printer/
ASCII Format	ESC = n
Dec. Format	[027][061] n {n=1,2,3}
Hex. Format	[1Bh][3Dh][n]
Description	Select peripheral device When n = 01h, enable printer, disable display When n = 02h, disable printer, enable display When n = 03h, enable printer, enable display For CD7220D only: When n = 04h, display message for customer side When n = 05h, display message for operator side
ESC & s n m	/Set user-defined characters/
[a(p1...pa)]	
x(m-n+1) n	
ASCII Format	ESC & s n m [a(p1...pa)] x (m-n+1) s=1
Dec. Format	[027][038][001] n m [a(p1...pa)] x (m-n+1) 20h≤n≤m≤FFh
Hex. Format	[1Bh][26h][01h][n][m][a(p1...pa)] x (m-n+1) 0≤a≤5 0≤p1...pa≤255
Description	The n defines the beginning character code, and m defines the ending character code. When only one character is defined, use n = m The “a” denotes the number of dots in the horizontal direction. When a < 5, the dot pattern for “a” on the right side of the user-defined characters are padded with spaces p1... pa, the dot data is to defined the characters. This indicates the dot pattern for “a” in the horizontal direction from the left side.
ESC % n	/Reset user defined character set/
ASCII Format	ESC % n
Dec. Format	[027][037] n {n=0 or 1 }
Hex. Format	[1Bh][25h][n]
Description	When n=1, user-defined characters are selected. When the user-defined characters are not defined by the ESC & command, the internal character set will be displayed. When n=0, user-defined characters are cancelled and the international character set is selected.
ESC ? n	/Cancel user defined characters/
ASCII Format	ESC ? n
Dec. Format	[027][063] n {20h≤n≤FFh or 1 }
Hex. Format	[1Bh][3Fh][n]
Description	User-defined characters are cancelled. This command cancels the defined characters specified by n. If specified code is transmitted after the pattern is cancelled, the international character will be displayed.
ESC s 1	/Store the user defined character into EEPROM. (EEPROM type only)/
ASCII Format	ESC s 1
Dec. Format	[027][115] [001]
Hex. Format	[1Bh][73h][01h]
Description	This command is successful when the display is selected under command ESC=03h If EEPROM is not supported, this command is ignored.
ESC d 1	/Restore the user defined character from EEPROM. (EEPROM type only)/
ASCII Format	ESC d 1
Dec. Format	[027][100] [001]
Hex. Format	[1Bh][64h][01h]
Description	CD7220 will restore user-defined characters from EEPROM, and the user-defined characters will be selected. If EEPROM is not supported, this command is ignored.

CD-7220-UN 5V USB SERIES CUSTOMER DISPLAY

7. INSTALLATION GUIDE

CD-7220-UN 5V USB series customer pole display can use with easy to connect USB port, when COM simulation driver is selected. Then CD-7220-UN 5V USB will be virtual USB device. When direct USB driver is selected, then CD-7220-UN 5V USB will be true USB device.